

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
AXIS (ONVIF)	F41 Main Unit	6.50.3	Yes	
AXIS (ONVIF)	M1124	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	M1124-E	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	M1125	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	M1125-E	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	M1145-L	6.50.3	Yes	
AXIS (ONVIF)	M3037-PVE	6.55.1.1	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
AXIS (ONVIF)	M3045-V	8.50.1	Yes with restriction	Multicast stream is not supported. IP Decoding Box does not support 1fps.
AXIS (ONVIF)	M3058-PLVE	8.50.1	Yes with restriction	Multicast stream is not supported.
AXIS (ONVIF)	M7011	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	M7014	5.51.5.1	Yes	
AXIS (ONVIF)	M7016	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	P1365 MkII	8.50.1	Yes with restriction	Multicast stream is not supported.
AXIS (ONVIF)	P1435-LE	8.50.1	Yes with restriction	Multicast stream is not supported.
AXIS (ONVIF)	P3905-RE	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	Q7404	5.51.5.1	Yes	
AXIS (ONVIF)	V5914	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
AXIS (ONVIF)	V5915	5.75.1.11	Yes	
BOSCH	NBN-71027-BA	6.60.0065	Yes	
BOSCH	NDP-4502-Z12	7.50.0079	Yes with restriction	Home position change is not available. Manual focus operation is not available. Auto focus operation is not available.
BOSCH	NTI-50022-V3	6.60.0065	Yes	
BOSCH	NUC-50022-F2	7.10.0076	Yes with restriction	PTZ function is not available.
Canon	VB-H45	1.1.4	Yes	
Canon	VB-H47	1.0.0	Yes with restriction	Preset function is not available. The RTP over RTSP operation is not available.
Canon	VB-M44	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-M46	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S32D	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S32VE	1.0.0	Yes with restriction	Preset function is not available. The RTP over RTSP operation is not available.
Canon	VB-S800D Mk II	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S805D Mk II	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S820D	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S900F Mk II	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S905F Mk II	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S920F	1.0.1	Yes with restriction	PTZ function is not available. The RTP over RTSP operation is not available.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Carina	NVT-DVI	2.0.0.5	Yes with restriction	1fps is not available.
Carina	NVT-SDI	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Dallmeier	DDF5050HDV	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF5120HDV-DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF5140HDV-DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF5250HDV-DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF5450HDV-DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF6400DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDF6800DN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDZ5220HD Indoor	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDZ5220HD Outdoor	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDZ5232HD Indoor	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDZ5232HD Outdoor	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DDZ5236HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Dallmeier	DDZ5436HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DF5050HDV	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DF5120HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DF5140HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DF5250HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	DF5450HD-DN/IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	RDF6400DN-IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
Dallmeier	RDF6800DN-IR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. [Common restrictions of Dallmeier] This information is the result of a compatibility test conducted by Dallmeier (https://www.dallmeier.com/).
FUJIFILM	SX800	1.3	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. The "EIZO Profile" is not available. The clock sync function is not available. Camera function settings on the GUI of our products are not supported. MJPEG stream is not available. Brightness operation is not available. Focus operation is not available. Joystick Mode is not available. When registering the camera, please set 8080 as the port number.
IDIS	DC-B3303X	2.0.0	Yes with restriction	The clock sync function is not available.
IDIS	DC-D4233HRX	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IDIS	DC-D4233RX	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
IDIS	DC-D4233WRX	2.2.0	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. The clock sync function is not available. Manual focus operation is not available. PTZ Adjustment function is not available. Joystick Mode is not available.
IDIS	DC-S3283FX	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IDIS	DC-S3283WHX	2.1.1	Yes with restriction	The clock sync function is not available. Manual focus operation is not available. PTZ Adjustment function is not available. Zoom Adjustment of Joystick Mode is not available.
IDIS	DC-T4233HRX	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IDIS	DC-T4233WRX	2.1.2	Yes with restriction	The clock sync function is not available. Manual focus operation is not available. Joystick Mode is not available.
IDIS	DC-Y3C14WRX	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IDIS	DC-Y8C13WRX	1.7.3	Yes with restriction	Camera function settings on the GUI of our products are not supported. The clock sync function is not available. Brightness operation is not available.
IKEGAMI	IPD-BL210-A	2.800.1041000.0.R	Yes with restriction	Focus operation is not available. The "EIZO Profile" is not available. Camera function settings on the GUI of our products are not supported.
IKEGAMI	IPD-BX210-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IKEGAMI	IPD-PT210-A Type Z	2.800.1041000.0.R	Yes with restriction	Focus operation is not available. Camera function settings on the GUI of our products are not supported.
IKEGAMI	IPD-SP210-A	2.810.1041000.0.R	Yes with restriction	Focus operation is not available. The "EIZO Profile" is not available. Camera function settings on the GUI of our products are not supported.
IKEGAMI	IPD-SP210U-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
IKEGAMI	IPD-VR210-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H158WPR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H168WPR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H258R	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H258VPR	1.00.000	Yes with restriction	Https is not available. Camera function settings on the GUI of our products are not supported. When using EIZO Profile, multicast stream is not available. Brightness operation is not available. Auto focus operation is not available. Zoom operation is not available.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
JVC	VN-H268R	1.27.006	Yes with restriction	PTZ operation is not available. Multicast stream is not available. The RTP over RTSP operation is not available.
JVC	VN-H268VPR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H58	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-H678WPR	1.02.002	Yes with restriction	Manual focus operation is not available. Auto focus operation is not available. PTZ operation is not available.
JVC	VN-H68	1.15.003	Yes with restriction	PTZ operation is not available. Multicast stream is not available.
JVC	VN-U178WPR	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	VN-U78	1.13.013	Yes with restriction	When using EIZO Profile, the preset function is not available. PTZ operation is not available.
MIKAMI	PTC-113 II -HDIP	PTZ F/W : Ver. 1.15 ENC F/W : Ver. 2.17	Yes with restriction	Preset function is not available. Camera function settings on the GUI of our products are not supported.
MITSUBISHI	NC-9000	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9020	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
MITSUBISHI	NC-9600	0109t	Yes with restriction	Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9620	0109t	Yes with restriction	Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MITSUBISHI	NC-9820	0109t	Yes with restriction	The camera cannot be automatically detected. Register the camera manually. Manual focus operation is not available. Auto focus operation is not available. Zoom operation is not available. Camera function settings on the GUI of our products are not supported. To display H.265 stream, register the camera with "DirectUri" protocol. About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the camera manufacturer. If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change cannot be performed.
MOBOTIX	c26	MX-V5.2.1.4	Yes with restriction	The video settings must be changed on the camera's web UI. After changing the video settings, it must also be saved on the camera's web UI. Supported Media Profiles are "Default H.264 Profile" and "Default MJPEG Profile". The "EIZO Profile" is not available.
SHARP	YK-B021C	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
SHARP	YK-B021F	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
SHARP	YK-B081F	5.5.53	Yes with restriction	Zoom adjustment takes about 10 seconds.
SHARP	YK-D021B	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
SHARP	YK-D021F	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
SHARP	YK-D081F	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
SHARP	YK-P021F	5.5.3	Yes with restriction	Focus operation is not available. Zoom-in operation is not available.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
SHARP	YK-P041G	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C3100-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C3200-3	1.3.0	Yes with restriction	Camera function settings on the GUI of our products are not available.
TOA	N-C3300F2	1.1.2	Yes with restriction	Camera function settings on the GUI of our products are not available. Digital Zoom(8 Step) operation is not available.
TOA	N-C5120-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5150	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5150-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5220-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5250R3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5420-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5450R3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5500	1.5.0	Yes with restriction	Video settings on the GUI of our products are not available. Home position change is not available. H.265 is available. When using H.265, Video settings on the GUI of our products are not available.
TOA	N-C5700	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5820-3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5850R3	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	CC9380-HV	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	CC9381-HV	2.2002.13.01r	Yes with restriction	PTZ function is not available. Preset function is not available. MJPEG stream is not available. Multicast stream is not available. Camera function settings on the GUI of our products are not supported.
VIVOTEK	FD9165-HT-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	FD9187-HT-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	FD9365-EHTV-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	FD9365-HTV-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	FD9368-HTV	2.2002.13.01j	Yes with restriction	Auto focus operation is not available. PTZ function is not available. Preset function is not available. MJPEG stream is not available. Multicast stream is not available. Camera function settings on the GUI of our products are not supported.
VIVOTEK	FD9369	1.2101.41.01l	Yes with restriction	PTZ function is not available. Preset function is not available. Camera function settings on the GUI of our products are not supported.
VIVOTEK	FD9387-EHTV-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	FD9387-HTV-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
VIVOTEK	FD9388-HTV	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	IB9365-EHT-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	IB9365-HT-A	0101b	Yes with restriction	Auto focus operation is not available. Brightness operation is not available. PTZ function is not available. Preset function is not available. Camera function settings on the GUI of our products are not supported.
VIVOTEK	IB9368-HT	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	IB9369	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	IB9387-EHT-A	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	IB9387-HT-A	0101b	Yes with restriction	Auto focus operation is not available. Brightness operation is not available. PTZ function is not available. Preset function is not available. Camera function settings on the GUI of our products are not supported.
VIVOTEK	IB9388-HT	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	SD9368-EHL	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
VIVOTEK	SD9384-EHL	1.2101.35.01i	Yes with restriction	Focus operation is not available. Brightness operation is not available. Preset function is not available. Multicast stream is not available. Camera function settings on the GUI of our products are not supported.