Maker	Camera	Firmware	Compatibility	Restriction/Explanation
				Disable "RTP B2 Frame" setting on the encoder Web UI.
A OT: (: DDO)				The RTP over RTSP operation is not available.
	V2224	A1D-600-H1.06.06- NB	Yes with restriction	The clock sync function is not available.
				The "EIZO Profile" is not available.
ACTi (i-PRO)				1fps is not available.
				Camera function settings on the GUI of our products are not supported.
				Https is not available.
				It is necessary to apply system software Ver.6.20 or later to our products.
	VB-H47	1.0.0	Yes with restriction	Preset function is not available.
Canon				The RTP over RTSP operation is not available.
				Camera function settings on the GUI of our products are not supported.
Canon	VB-M46	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Canon	VB-S32D	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
			Yes with restriction	Preset function is not available.
Canon	VB-S32VE	1.0.0		The RTP over RTSP operation is not available.
				Camera function settings on the GUI of our products are not supported.
Canon	VB-S820D	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				PTZ function is not available.
Canon	VB-S920F	1.0.1	Yes with restriction	The RTP over RTSP operation is not available.
				Camera function settings on the GUI of our products are not supported.
JVC	VN-H158WPR	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
3,40				H.264 is not available.
JVC	VN-H168WPR	-	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H258R	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
3,0	VIN TIZJUN			H.264 is not available.
JVC	VN-H258VPR	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				H.264 is not available.
JVC	VN-H268R	_	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H268VPR	-	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H58	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				H.264 is not available.
JVC	VN-H658	1.00.079	Yes with restriction	The "EIZO Profile" is not available.
				Https is not available.
				PTZ operation is not available.
				Brightness operation is not available.
				Manual focus operation is not available.
				Auto focus operation is not available.
				Multicast stream is not available.
				H.264 is not available.



Maker	Camera	Firmware	Compatibility	Restriction/Explanation
JVC	VN-H658WP		Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
JVC	V1V-11030VV1			H.264 is not available.
JVC	VN-H678WPR	_	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-H68	_	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-U178WPR	_	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
JVC	VN-U78	_	No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
			Yes with restriction	The camera cannot be automatically detected. Register the camera manually.
				Manual focus operation is not available.
				Auto focus operation is not available.
	NC-9000	0109t		Zoom operation is not available.
MITSUBISHI				Camera function settings on the GUI of our products are not supported.
WITTOODIOTII	140 3000			To display H.265 stream, register the camera with "DirectUri" protocol.
				About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the
				camera manufacturer.
				If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change
				cannot be performed.
				The camera cannot be automatically detected. Register the camera manually.
	NC-9020	0109t	Yes with restriction	Manual focus operation is not available.
				Auto focus operation is not available.
				Zoom operation is not available.
MITSUBISHI				Camera function settings on the GUI of our products are not supported.
WITSODISTII				To display H.265 stream, register the camera with "DirectUri" protocol.
				About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the
				camera manufacturer.
				If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change
				cannot be performed.
	NC-9600	0109t	Yes with restriction	Manual focus operation is not available.
MITSUBISHI				Auto focus operation is not available.
				Zoom operation is not available.
				Camera function settings on the GUI of our products are not supported.
				To display H.265 stream, register the camera with "DirectUri" protocol.
				About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the
				camera manufacturer.
				If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change
				cannot be performed.



Maker	Camera	Firmware	Compatibility	Restriction/Explanation
				Manual focus operation is not available.
	NC-9620		Yes with restriction	Auto focus operation is not available.
		0109t		Zoom operation is not available.
				Camera function settings on the GUI of our products are not supported.
MITSUBISHI				To display H.265 stream, register the camera with "DirectUri" protocol.
				About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the
				camera manufacturer.
				If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change
				cannot be performed.
			Yes with restriction	The camera cannot be automatically detected. Register the camera manually.
				Manual focus operation is not available.
				Auto focus operation is not available.
				Zoom operation is not available.
MITSUBISHI	NC-9820	0109t		Camera function settings on the GUI of our products are not supported.
		01031		To display H.265 stream, register the camera with "DirectUri" protocol.
				About the RTSP stream URI (URI starting with rtsp://) to be entered in the URI, refer to the camera's user manual or contact the
				camera manufacturer.
				If you connect a camera using "DirectUri" protocol, the image can be displayed, but the camera's PTZ operation and setting change
T0.4	N. 00400 0		\(\frac{1}{2}\)	cannot be performed.
TOA	N-C3100-3	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C3120	1.3.0	Yes	
TOA	N-C3200-3	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
	N-C3300F2	1.1.2	Yes with restriction	Camera function settings on the GUI of our products are not supported.
ТОА				Brightness operation is not available.
				Zoom operation is not available. Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
ТОА	N-C5120-3	_	Yes (Video display)	When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
TOA				Preset function is not available.
TOA	N-C5150	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
ТОА	N-C5150-3	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
ТОА	N-C5220-3	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
		1	1	



	Camera	Firmware	Compatibility	Restriction/Explanation
				Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5250R3	_	Yes (Video display)	When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
				Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5420-3	-	Yes (Video display)	When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
			Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5450R3	_		When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
			Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5500	_		When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
TOA	N-C5500A	1.9.3	Yes with restriction	When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
TOA	N-C3300A	1.9.5	res with restriction	Preset function is not available.
			Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5700	_		When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
				Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5700A	_	Yes (Video display)	When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
		-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA	N-C5820-3			When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
	N-C5850R3	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
TOA				When you change the camera's imaging mode while using EIZO_Profile, re-register the camera.
				Preset function is not available.
	N-V5020-1	_	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
				Camera function settings on the GUI of our products are not supported.
				When you change the encoder's imaging mode while using EIZO_Profile, re-register the encoder.
TOA				When a TOA AHD camera (AH-C1714/AH-C1701/AH-C1501) is connected to the encoder, the PTZ function is available, but the
				joystick mode is not available.
				Preset position registration function is not available.
				Home positon registration function is not available.
	N-V5050P1	1.9.2	Yes with restriction	Camera function settings on the GUI of our products are not supported.
				When you change the encoder's imaging mode while using EIZO_Profile, re-register the encoder.
TOA				When a TOA AHD camera (AH-C1714/AH-C1701/AH-C1501) is connected to the encoder, the PTZ function is available, but the
TOA				joystick mode is not available.
				Preset position registration function is not available.
				Home positon registration function is not available.

