

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic Integrated Camera	AW-HE40	-	Yes (Video display)	<p>Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Set the Priority Mode of the camera to "IP" and then enable "H.264 transmission". Set the H.264 configuration of resolution and other settings from the camera's web settings. Home position preset change is not available. When the camera's brightness is controlled from the IP decoding monitor, disable the auto brightness function of the camera. When the camera's focus is controlled from the IP decoding monitor, disable the auto focus function of the camera. [Common restrictions of Panasonic Integrated Camera] 20 minutes after turning on the camera, the IP decoding monitor can no longer detect it. (With specific cameras only.) If the LAN cable is unplugged or IP decoding monitor is turned off, there are cases in which it takes about 2 minutes for live display again. If automatic camera detection is executed right after the Panasonic camera is turned on, it may be recognized as an ONVIF camera that is not Panasonic. IP decoding monitor does not support the BB-HCM series cameras.</p>
Panasonic Integrated Camera	AW-HE65	-	Yes (Video display)	<p>Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Set the Priority Mode of the camera to "IP" and then enable "H.264 transmission". Set the H.264 configuration of resolution and other settings from the camera's web settings. Home position preset change is not available. When the camera's brightness is controlled from the IP decoding monitor, disable the auto brightness function of the camera. When the camera's focus is controlled from the IP decoding monitor, disable the auto focus function of the camera. [Common restrictions of Panasonic Integrated Camera] 20 minutes after turning on the camera, the IP decoding monitor can no longer detect it. (With specific cameras only.) If the LAN cable is unplugged or IP decoding monitor is turned off, there are cases in which it takes about 2 minutes for live display again. If automatic camera detection is executed right after the Panasonic camera is turned on, it may be recognized as an ONVIF camera that is not Panasonic. IP decoding monitor does not support the BB-HCM series cameras.</p>
Panasonic Integrated Camera	AW-HE70	HE70 1.21 HE70SW -	Yes with restriction	<p>Set the Priority Mode of the camera to "IP" and then enable "H.264 transmission". Set the H.264 configuration of resolution and other settings from the camera's web settings. Home position preset change is not available. When the camera's brightness is controlled from the IP decoding monitor, disable the auto brightness function of the camera. When the camera's focus is controlled from the IP decoding monitor, disable the auto focus function of the camera. [Common restrictions of Panasonic Integrated Camera] 20 minutes after turning on the camera, the IP decoding monitor can no longer detect it. (With specific cameras only.) If the LAN cable is unplugged or IP decoding monitor is turned off, there are cases in which it takes about 2 minutes for live display again. If automatic camera detection is executed right after the Panasonic camera is turned on, it may be recognized as an ONVIF camera that is not Panasonic. IP decoding monitor does not support the BB-HCM series cameras.</p>

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic Integrated Camera	AW-UE70	1.11	Yes with restriction	Set the Priority Mode of the camera to "IP" and then enable "H.264 transmission". Set the H.264 configuration of resolution and other settings from the camera's web settings. Home position preset change is not available. When the camera's brightness is controlled from the IP decoding monitor, disable the auto brightness function of the camera. When the camera's focus is controlled from the IP decoding monitor, disable the auto focus function of the camera. [Common restrictions of Panasonic Integrated Camera] 20 minutes after turning on the camera, the IP decoding monitor can no longer detect it. (With specific cameras only.) If the LAN cable is unplugged or IP decoding monitor is turned off, there are cases in which it takes about 2 minutes for live display again. If automatic camera detection is executed right after the Panasonic camera is turned on, it may be recognized as an ONVIF camera that is not Panasonic. IP decoding monitor does not support the BB-HCM series cameras.
Panasonic i-PRO EXTREME	WV-S1110V	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1110VRJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1111	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1112	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1115V	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1116	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1116D	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1130V	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1130VRJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1131	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1135V	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1136J	1.21	Yes with restriction	Camera title position cannot be changed. Focus and Zoom functions are not supported.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-S1510	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1511LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1515L	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1516LDN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1516LN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1531LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1531LNSJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1531LTNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S1536LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1536LTNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S1550LNJ	–	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-S1552LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S1570LNJ	–	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-S1572LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S2110J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WVS2110RJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2111L	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-S2115	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2116L	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2116LD	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2130	1.82	Yes with restriction	Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2130RJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2131L	1.45	Yes with restriction	IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2135	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2136LJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2511LN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2531LN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2531LTN	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. IP decoding monitor does not support 1fps.
Panasonic i-PRO EXTREME	WV-S2536LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2536LTNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-S2550LNJ	1.10	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-S2552LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S2570LNJ	4.2.1	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-S2572LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S3110J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S3130J	2.01	Yes	
Panasonic i-PRO EXTREME	WV-S3510J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S3530J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S4150	1.11	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-S4156J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. When the camera's "Image capture mode" is "Quad stream", brightness operation for each channel is not available. When the camera's "Image capture mode" is "Quad stream", Ch1 presets is not available. Focus function is not supported. Multicast stream is not supported. Auxiliary command is not supported.
Panasonic i-PRO EXTREME	WV-S4176J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. When the camera's "Image capture mode" is "Quad stream", brightness operation for each channel is not available. When the camera's "Image capture mode" is "Quad stream", Ch1 presets is not available. Focus function is not supported. Multicast stream is not supported. Auxiliary command is not supported.
Panasonic i-PRO EXTREME	WV-S4550L	–	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-S4556LJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. When the camera's "Image capture mode" is "Quad stream", brightness operation for each channel is not available. When the camera's "Image capture mode" is "Quad stream", Ch1 presets is not available. Focus function is not supported. Multicast stream is not supported. Auxiliary command is not supported.
Panasonic i-PRO EXTREME	WV-S4576LJ	2.00	Yes with restriction	When the camera's "Image capture mode" is "Quad stream", brightness operation for each channel is not available. When the camera's "Image capture mode" is "Quad stream", Ch1 presets is not available. Focus function is not supported. Multicast stream is not supported. Auxiliary command is not supported.
Panasonic i-PRO EXTREME	WV-S6110	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-S6111	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S6130	1.82	Yes	
Panasonic i-PRO EXTREME	WV-S6131	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S6530NJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S6530NS	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S6532LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S8530	1.04	Yes	
Panasonic i-PRO EXTREME	WV-S8530N	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-S8531N	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-U1113AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1113J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1114AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1114J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1133AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1133J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1134AJ	1.40	Yes with restriction	Camera title position cannot be changed. Focus and Zoom functions are not supported.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-U1134J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1533AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U1533J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U2114AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U2114J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U2134AJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-U2134J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-X1534LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-X1571LNJ	1.20	Yes with restriction	Camera title position cannot be changed. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-X2232LJ	1.00	Yes with restriction	Set the H.264 configuration of resolution and other settings from the camera's web settings. Focus and Zoom functions are not supported.
Panasonic i-PRO EXTREME	WV-X2533LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-X2571LNJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-X4171	–	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-X4571L	–	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-X6511NJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-X6531NJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO EXTREME	WV-X6531NS	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO EXTREME	WV-X6533LNJ	1.01	Yes	
Panasonic i-PRO EXTREME	WV-X8570N	-	No	There is a compatibility problem. The camera cannot be used in combination with this decoder. Supported by DX0211-IP / FDF2711W-IP.
Panasonic i-PRO EXTREME	WV-X8571N	1.03	Yes with restriction	Camera title position cannot be changed. Zoom function is not supported. Multicast stream is not supported.
Panasonic i-PRO SmartHD	BB-HCM series		No	There is a compatibility problem. The camera cannot be used in combination with this decoder.
Panasonic i-PRO SmartHD	BB-SC364	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SC382	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SC384	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SC384A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SC384B	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SP104W	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-ST162	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-ST162A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-ST165	Application 2.00 Image data 1.03	Yes	
Panasonic i-PRO SmartHD	BB-ST165A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW172	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW172A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW174W	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW174WA	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	BB-SW175	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW175A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BB-SW374	Application 4.30 Driver 1.01 Image data 1.00	Yes	
Panasonic i-PRO SmartHD	BL-VP101	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BL-VP104	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BL-VP104W	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BL-VT164	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	BL-VT164W	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-GXE100	1.82	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. When changing the aspect ratio in the Video settings, there is a case that the IP decoding monitor cannot communicate with the camera for a couple of minutes. When using the camera's D1 720 x 576 mode, Video settings should be done via the camera's Web Setup window.
Panasonic i-PRO SmartHD	DG-GXE500	1.54	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. When changing the aspect ratio in the Video settings, there is a case that the IP decoding monitor cannot communicate with the camera for a couple of minutes. When using the camera's D1 720 x 576 mode, Video settings should be done via the camera's Web Setup window.
Panasonic i-PRO SmartHD	DG-NP502	Application 2.0 Driver 1.10 Image data 1.04	Yes	
Panasonic i-PRO SmartHD	DG-NW502S	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SC385	Application 1.44 / 2.02 Driver 1.31 / 1.52 Image data 1.16	Yes	
Panasonic i-PRO SmartHD	DG-SC386	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SF132	Application 1.44 Image data 1.03	Yes	
Panasonic i-PRO SmartHD	DG-SF135	-	Yes	

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	DG-SF334	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SF335	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SF438	Application 1.45 Image data 1.15	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	DG-SF539	Application 1.23 Image data 2.16	Yes	
Panasonic i-PRO SmartHD	DG-SP102	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SP304V	Application 1.66 Image data 2.02	Yes	
Panasonic i-PRO SmartHD	DG-SP305	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SP509	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW155	-	Yes	
Panasonic i-PRO SmartHD	DG-SW155M	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW314	Application 1.40 Image data 2.00	Yes	
Panasonic i-PRO SmartHD	DG-SW316	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW316L	Application 1.81 Image data 1.08	Yes	
Panasonic i-PRO SmartHD	DG-SW355	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW395	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW395A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW396	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW396A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	DG-SW458		Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	DG-SW458M	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	DG-SW559	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WJ-GXE100	Application 2.01	Yes with restriction	When changing the aspect ratio in the Video settings, there is a case that the IP decoding monitor cannot communicate with the camera for a couple of minutes. When using the camera's D1 720 x 576 mode, Video settings should be done via the camera's Web Setup window.
Panasonic i-PRO SmartHD	WJ-GXE500	1.54 / 1.60	Yes with restriction	When changing the aspect ratio in the Video settings, there is a case that the IP decoding monitor cannot communicate with the camera for a couple of minutes. When using the camera's D1 720 x 576 mode, Video settings should be done via the camera's Web Setup window.
Panasonic i-PRO SmartHD	WV-NP502	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-NW502S	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SC384	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SC385	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SC386	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SC387	Application 1.70 Driver 1.00 Image data 1.00	Yes	
Panasonic i-PRO SmartHD	WV-SC588	Application 1.50 Driver 1.90 Image data 3.30	Yes	
Panasonic i-PRO SmartHD	WV-SF132	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF135	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF138	Application 1.5 Image data 1.07	Yes	
Panasonic i-PRO SmartHD	WV-SF332	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF335	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF336	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	WV-SF342	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF346	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF438	Application 1.52 Image data 1.19	Yes with restriction	Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	WV-SF448E	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	WV-SF538	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF539	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF548	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SF549	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SFN110	2.40	Yes	
Panasonic i-PRO SmartHD	WV-SFN130	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SFN3 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SFN480	2.02	Yes with restriction	When the camera's "Image capture mode" is "Quad stream" and the software version is 2.00 or earlier, the IP decoding monitor cannot display Channel 1. When the camera's "Image capture mode" is "Quad stream" or "Quad PTZ", the IP decoding monitor cannot move the preset position. Registration of the preset position is not available. Focus function is not supported.
Panasonic i-PRO SmartHD	WV-SFN531	1.85	Yes with restriction	Focus and Zoom functions are not supported.
Panasonic i-PRO SmartHD	WV-SFN6 series	1.54	Yes with restriction	Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SFR3 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SFR6 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	WV-SFV110	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SFV130	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SFV3 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SFV481	1.11 / 2.5	Yes with restriction	When the camera's "Image capture mode" is "Quad stream" and the software version is 2.00 or earlier, the IP decoding monitor cannot display Channel 1. When the camera's "Image capture mode" is "Quad stream" or "Quad PTZ", the IP decoding monitor cannot move the preset position. Registration of the preset position is not available. Focus function is not supported.
Panasonic i-PRO SmartHD	WV-SFV6 series	Application 1.4	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SFV781L	2.5	Yes with restriction	When the camera's "Image capture mode" is "Cropping" and the software version is 2.00 or earlier, the IP decoding monitor cannot display Channel 1. When the camera's "Image capture mode" is "Cropping", the IP decoding monitor cannot move and change the Home position. Zoom function is not supported.
Panasonic i-PRO SmartHD	WV-SP102	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP105	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP302	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP305	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP306	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP508	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP509	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SP509J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SPN3 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported.
Panasonic i-PRO SmartHD	WV-SPN5 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	WV-SPN6 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported. Updating the camera's firmware to version 1.53 or later is required.
Panasonic i-PRO SmartHD	WV-SPN6R481	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SPV781 series	1.05 / 2.40	Yes with restriction	When the camera's "Image capture mode" is "Cropping" and the software version is 2.00 or earlier, the IP decoding monitor cannot display Channel 1. When the camera's "Image capture mode" is "Cropping", the IP decoding monitor cannot move and change the Home position. Zoom function is not supported.
Panasonic i-PRO SmartHD	WV-SPW6 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Zoom function is not supported.
Panasonic i-PRO SmartHD	WV-ST162	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-ST165	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SUD638	Application 2.42 Driver 1.31 Image data 1.16	Yes	
Panasonic i-PRO SmartHD	WV-SW115	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW152	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW152M	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW155	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW155M	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW158	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW172	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW174W	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW175	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW314	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW314J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	WV-SW316	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW316J	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW316L	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW316LJ	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW352	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW355	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW395	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW395A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW395AJ	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW395J	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW396	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW396A	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW396AJ	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW396J	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW397 series	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW458	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	WV-SW458M	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand. Home position preset change is not available. Do not set to H.264 resolution via the IP decoding monitor when using Stream 1.
Panasonic i-PRO SmartHD	WV-SW558	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW559	–	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.

Maker	Camera	Firmware	Compatibility	Restriction/Explanation
Panasonic i-PRO SmartHD	WV-SW598	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.
Panasonic i-PRO SmartHD	WV-SW598J	-	Yes (Video display)	Only video display is confirmed. If PTZ or other functions are required, please confirm with the actual devices beforehand.